

**SELEC**<sup>®</sup>  
Creating Best Value



# MFM384

## Multifunction Meter

*Operating / 1004 / MFM384 / Ver1, OP278-V01.*

**Selec Controls Pvt. Ltd., India,**

**Tel:** 91-22-28471882 / 4039 4200 / 4039 4202

**Tollfree:** 1800 227 353 **Fax:** 91-22-28471733,

**Website:** [www.selec.com](http://www.selec.com)

**E- mail:** [sales@selec.com](mailto:sales@selec.com)

# OPERATING INSTRUCTIONS

*Operating / 1004 / MFM384 / Ver1, OP278-V01.*

<b>1. INTRODUCTION</b>	
1.1 About MFM384.....	01
1.2 Overview.....	02
1.3 Technical Overview.....	04
1.4 Installation Guide.....	08
1.5 Wiring Guide.....	11
<b>2. HMI</b> .....	15
<b>3. CONFIGURATION</b> .....	21
<b>4. APPLICATIONS</b> .....	29
<b>5. COMMUNICATION</b>	
5.1 Modbus Parameter.....	30
<b>6. USER GUIDE</b> .....	38
<b>7. CONFIG RECORD SHEET</b> .....	39

Config page.	Function	Value or Selection	Factory Setting
13.7	Page sequence 7	_____	7
13.8	Page sequence 8	_____	8
13.9	Page sequence 9	_____	9
13.10	Page sequence 10	_____	10
13.11	Page sequence 11	_____	11
13.12	Page sequence 12	_____	12
13.13	Page sequence 13	_____	13
13.14	Page sequence 14	_____	14
13.15	Page sequence 15	_____	15

**ABOUT MFM384**

A suitable meter for the measurement of parameters such as voltage, current, power factor, frequency, power and energy. Features such as pulse output, communication are available thereby providing a complete solution for many measurement needs.

**APPLICATION AREA:**

Electric Automation SCADA System:

MFM384 can be used as Remote Terminal Unit (RTU) for monitoring purpose in a SCADA System. All measured data is available through RS485 communication ports with the Modbus Protocol.

Energy Management System / Building Management System:

MFM384 can be used to monitor power and energy parameters of an organisation which can be transmitted to main control room through RS485

**HEAVY INDUSTRIES:**

MFM384 is a suitable meter for heavy industries because of its ability to function even in rough conditions.

**APPLICATION FIELD:**

1. Power Transmission and Distribution field
2. Power System Protection Field
3. Industry Automation
4. Large UPS System

**Note:** Please read this manual carefully & completely before installing / operating MFM384.

**Specifications subject to change as development is a continuous process**

## Overview



## SALIENT FEATURES

- 4 lines, 4 digits per line, 8 digits for energy
- Bar graph for current indication
- Network supported: 1 Ø 2 wire, 1 Ø 3 wire, 2 Ø 3 wire, 3 Ø 3 wire, 3 Ø 4 wire
- User programmable network selection
- LCD with backlight
- User programmable ON time for backlight
- Auto / manual page scrolling
- User programmable page sequence for page displayed in auto mode
- Measures all electrical parameters (RMS Voltage, Current, Active power, Reactive power, Apparent power, Power factor, Frequency, Active energy, Reactive energy & Apparent energy )
- Programmable CT/ PT primary, CT/PT secondary
- Memory retention for ten years
- Potential free Pulse output for energy
- 90 to 270V AC auxiliary supply
- RS485 communication (MODBUS Protocol)
- Protection covering for terminal screws

## ORDER CODE

MFM384

Config page.	Function	Value or Selection	Factory Setting
	Password	_____	1000
1	Change Password	_____	No
1.1	New Password	_____	-
2	Network Selection	_____	3P4W
3	CT Secondary	_____	5
4	CT Primary	_____	00005
5	PT Secondary	_____	350
6	PT primary	_____	350
7	Slave Id	_____	001
8	Baud Rate	_____	9600
9	Parity	_____	None
10	Stop Bit	_____	1
11	Back Light	_____	0000
12	Max Page Auto	_____	15
13	Change Page Sequence	_____	No
13.1	Page sequence 1	_____	1
13.2	Page sequence 2	_____	2
13.3	Page sequence 3	_____	3
13.4	Page sequence 4	_____	4
13.5	Page sequence 5	_____	5
13.6	Page sequence 6	_____	6

## Description of Parameter &amp; Symbols

- VOLTAGE:** True RMS value of three phase voltage, three line to line voltages and their average values are measured and displayed on MFM384.
- CURRENT:** True RMS value of three phase currents and their average are measured and displayed in MFM384. There is also Bar graph presentation for current in percentage form.
- POWER FACTOR:** Individual and average power factor displayed on MFM384
- ACTIVE POWER (P):** Three phase active power and system total active power are measured and displayed on MFM384.
- REACTIVE POWER(Q):** Three phase reactive power and total reactive power of the system are measured and displayed on MFM384.
- APPARENT POWER (S):** Three phase apparent power and total apparent power of the system are measured and displayed on MFM384.
- FREQUENCY:** The frequency of available voltage input is measured as system frequency.
- ENERGY (kWh, kVAh, kVAh):** Total Active, Reactive and Apparent energy of the system is measured and displayed on MFM 384.
- PULSE O/P:** DC pulse output is generated by the MFM384 which can be used to interface MFM384 with SCADA systems.
- 'INT':** It indicates the integration of power available in the transmission lines. It blinks once after every 5 sec.
- '↔':** This symbol indicates that communication is in progress.

## Overview

## Display &amp; Key description

- Bargraph  
Display current in bargraph format
- 4 lines of seven segment digits in metering area  
Display parameters such as voltage, Current, Power factor, Power & Frequency
- Unit (V, A, PF, Hz, kW, kVA, kVA)  
Indicates unit of parameter to be measured



Voltage: V, kV		Current: A
Active Power: kW, MW		Reactive power: kVA, MVA
Apparent power: kVA, MVA		Frequency: Hz,
Energy: kWh, MWh		Reactive energy: kVAh, MVAh
Apparent energy: kVAh, MVAh		

- Integration of energy: Energy accumulation indication
- Keypad: keypad with six dual function keys (HMI or Programming)
- Energy: 8 dedicated digits for energy (Active, Reactive & Apparent)
- Backlight: Backlight LCD display (ON / OFF time programmable, auto ON on key press)
- Phase (1, 2, 3, 1-2, 2-3, 3-1) : Display phase to neutral or phase to phase values



MODBUS register addresses list *continued*

Readable parameters from MFM384

Address	Hex Address	Parameter
40017	0x11	Auto Mode Pgs
40018	0x12	Page Address Sequence
40019	0x13	Page Address Sequence
40020	0x14	Page Address Sequence
40021	0x15	Page Address Sequence
40022	0x16	Page Address Sequence
40023	0x17	Page Address Sequence
40024	0x18	Page Address Sequence
40025	0x19	Page Address Sequence
40026	0x1A	Page Address Sequence
40027	0x1B	Page Address Sequence
40028	0x1C	Page Address Sequence
40029	0x1D	Page Address Sequence
40030	0x1E	Page Address Sequence
40031	0x1F	Page Address Sequence
40032	0x20	Page Address Sequence

**Serial Communication**

Interface standard & protocol	RS485 & MODBUS RTU
Communication address	1 to 255
Transmission mode	Half duplex
Data types	Float and Integer
Transmission distance	500 m maximum
Transmission speed	300, 600, 1200, 2400, 4800, 9600, 19200 (in bps)
Parity	None, Odd, Even
Stop bits	1 or 2
Response time	100 ms (Independent of baud rate)

**Pulse Output**

Pulse Output (type)	Opto-Isolated
Pulse Voltage	24V DC max.
Pulse Current	100mA max.
Pulse Width	100 ms $\pm$ 50 ms.

**General Specification**

Auxiliary Supply	90 to 270V AC/DC
Operating frequency	50/60Hz
Power Consumption	0.5 VA max. @5A per phase
Temperature	Operating temperature: 0 to +50°C Storage temperature: -20 to +75°C
Humidity	85% RH
Mounting	Panel mounting
Weight	320 gms

Parameter Measured / Calculated		
Parameters	Measured values	Unit
Voltage	V1N, V2N, V3N, V12, V23, V31, Vavg L-N, Vavg L-L	V
Current	I <sub>1</sub> , I <sub>2</sub> , I <sub>3</sub> , I <sub>avg</sub>	A
Active Power	kW <sub>1</sub> , kW <sub>2</sub> , kW <sub>3</sub> & Total kW	kW
Reactive Power	kVAR <sub>1</sub> , kVAR <sub>2</sub> , kVAR <sub>3</sub> and Total kVAR	kVAR
Apparent Power	kVA <sub>1</sub> , kVA <sub>2</sub> , kVA <sub>3</sub> & Total kVA	kVA
Power Factor	Pf <sub>1</sub> , Pf <sub>2</sub> , Pf <sub>3</sub> , Avg Pf	-
Frequency	Hz	Hz
Active Energy	Total kWh	kWh
Reactive Energy	Total kVArh	kVArh
Apparent Energy	Total kVAh	kVAh

## Resolution Table

PT Ratio x CT Ratio	kWh	Pulse
<15	0.01K	0.01K
<150	0.1K	0.1K
<1500	1K	1K
<15000	0.01M	0.01M
<150000	0.1M	0.1M
<1500000	1M	1M
≥1500000	10M	10M

## NOTE:

- 1) For voltage, Current, Power, resolution is automatically adjusted
- 2) For power factor, resolution is 0.001
- 3) INT blinks after every 5 seconds, if load is connected on any one of 3 phase

Range		Length (Register)	Data Structure
Write Value	Meaning		
<b>Value</b>	<b>Meaning</b>		
1	255	1	Integer
<b>Value</b>	<b>Baud rate</b>		
0x0000	300	1	Integer
0x0001	600		
0x0002	1200		
0x0003	2400		
0x0004	4800		
0x0005	9600		
0x0006	19200		
<b>Value</b>	<b>Parity</b>		
0x0000	None	1	Integer
0x0001	Odd		
0x0002	Even		
<b>Min value</b>	<b>Maximum value</b>		
0	7200	1	Integer
1	Set to factory setting range		
<b>Value</b>	<b>Meaning</b>		
1	Reset Total Active Energy	1	Integer
1	Reset Total Apparent Energy	1	Integer
1	Reset Total Reactive Energy	1	Integer



## Installation Guide

## Safety Precautions


All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.  
If the equipment is not handled in a manner specified by the manufacturer it might impair the protection provided by the equipment.

**⚠ CAUTION:** Read complete instructions prior to installation and operation of the unit.

**⚠ CAUTION:** Risk of electric shock.

## WIRING GUIDELINES

## WARNING:

- To prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.
- Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
- Use lugged terminals.
- To eliminate electromagnetic interference use of wires with adequate ratings and twists of the same in equal size shall be made.
- Cable used for connection to power source, must have a cross section of 1.5mm<sup>2</sup>. These wires shall have current carrying capacity of 6A.
- The following safety earth symbol is used in this user's manual 

		Length (Register)	Data Structure
		2	Float
		2	Float
		2	Float
		2	Float
		2	Float
		2	Float
		2	Float
		2	Float
Range		Length (Register)	Data Structure
Min value	Max value		
0	9998	1	Integer
Value	Meaning		
0	3P-4W	1	Integer
1	3P-3W	1	Integer
Write Value	Meaning		
1		1	Integer
5			
5	10000	1	Integer
1	10000		
100	520	1	Integer
100	99.9KV	2	Integer

MODBUS register addresses list *continued***Readable parameters from MFM384:**

Address	Hex Address	Parameter
30046	0x2E	Total kVA <sub>r</sub>
30048	0x30	PF1
30050	0x32	PF2
30052	0x34	PF3
30054	0x36	Average PF
30056	0x38	Frequency
30058	0x3A	kWh
30060	0x3C	kVAh
30062	0x3E	kVA <sub>r</sub> h

**Readable / writable parameters from MFM384:**

Address	Hex Address	Parameter
40000	0x00	Password
40001	0x01	N/W selection
40002	0x02	CT Secondary
40003	0x03	CT primary (CT Secondary = 5)
40004	0x04	CT primary (CT Secondary = 1)
40005	0x05	PT Secondary
40006	0x06	PT primary

**Maintenance**

1. The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth. Do not use Isopropyl alcohol or any other cleaning agent.

**Installation Guidelines****⚠ CAUTION:**

1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case, the terminals do not remain accessible to the end user after installation and internal wiring.
2. Conductors must not come in contact with the internal circuitry of the equipment or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
3. Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
4. Before disconnecting the secondary of the external current transformer from the equipment, make sure that the current transformer is short circuited to avoid risk of electrical shock and injury.

**⚠ CAUTION:**

1. The equipment shall not be installed in environmental conditions other than those mentioned in this manual.
2. The equipment does not have a built-in-type fuse. Installation of external fuse of rating 275V AC/1Amp for electrical circuitry is highly recommended.




## MODBUS register addresses list


## Readable parameters from MFM384:

Address	Hex Address	Parameter
30000	0x00	Voltage V1N
30002	0x02	Voltage V2N
30004	0x04	Voltage V3N
30006	0x06	Average Voltage LN
30008	0x08	Voltage V12
30010	0x0A	Voltage V23
30012	0x0C	Voltage V31
30014	0x0E	Average Voltage LL
30016	0x10	Current I1
30018	0x12	Current I2
30020	0x14	Current I3
30022	0x16	Average Current
30024	0x18	kW1
30026	0x1A	kW2
30028	0x1C	kW3
30030	0x1E	kVA1
30032	0x20	kVA2
30034	0x22	kVA3
30036	0x24	kVAr1
30038	0x26	kVAr2
30040	0x28	kVAr3
30042	0x2A	Total kW
30044	0x2C	Total kVA

## Terminal Diagram





## Wiring guide

3 PHASE 4-WIRE (COMMONLY USED) WIRING DIAGRAM  
3  $\phi$  - 4 wire, 3 CT's


## Wiring Guide

## 3 Ø - 4 wire, 3 CT's &amp; 3 PT's

3 PHASE 3-WIRE WIRING DIAGRAM  
3 Ø - 3 wire, 2 CT's & 2 PT's


## Application of Pulse Output

## • Process Integration



Pulse output from MFM384 meter can be interfaced into a process through a PLC for on line control of energy content in the process. If the PLC has a self excited 24V digital input, external 24V DC supply is not needed. The kWh pulse is also used to derive average kWh information at the PLC.


## • Energy Controller




Pulse output from MFM384 meter can be used as alarm generator or total energy controller by interfacing it with presettable counter and control circuits (Contactors, Relay, Trip Circuit). The counter is loaded with the maximum energy consumption. When count reaches setpoint it provides output to control circuit to take appropriate action.



## Wiring Guide

1 PHASE 2-WIRE (COMMONLY USED) WIRING DIAGRAM  
1 Ø - 2 wire, 1 CT

## COMMUNICATION WIRING DIAGRAM



## Configuration



## Factory Default

**Default Setting:** No  
**Range:** No / Yes


**Note:** If 'Yes' selected unit will be formatted to factory default settings. User should note all previous settings before formatting the unit.



## Reset

**Default Setting:** No  
**Range:** No / Yes

**Note:** For resetting energy parameters user has to select 'Yes' option. If option selected is 'No' the configuration will move to change password.



## Password

**Default Setting:** 1001  
**Selection:** 0000 To 9999

**Note:** For resetting energy parameters user will be prompted the password. If correct password is entered, the user will be able to reset all energy parameters. This password will be a value which will be greater than the configuration password by 1.



## Online Page Description

04

X1



Press VAF (▼) button, the first screen shows:

- ✓ Voltage (L-N), Current, Power factor of first phase (V1, I1, PF1) & Frequency (Hz)
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
- ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

05

X2



Press VAF (▼) button, the second screen shows:

- ✓ Voltage (L-N), Current, Power factor of second phase (V2, I2, PF2) & Frequency (Hz)
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
- ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

06

X3



Press VAF (▼) button, the third screen shows:

- ✓ Voltage (L-N), Current, Power factor of third phase (V3, I3, PF3) & Frequency (Hz)
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
- ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

## Configuration

**Parity****Default Setting:** None**Range:** None, Even, Odd

**Note:** for asynchronous communication, user can select any one of three None, Even, Odd

**Stop Bit****Default Setting:** 1**Range:** 1 or 2

**Note:** for asynchronous communication, user can select any one of two 1 or 2

**Backlight****Default Setting:** 0 sec.**Range:** 0 to 7200 sec.

**Note:** Backlight remains on permanently if the time programmed is 0 second. User can switch OFF the backlight by entering a value within the defined range. The backlight switches OFF after the entered time elapses & automatically switches ON for time after detection of any key press

## Configuration

**PT Primary****Default Setting:** 350V**Range:** 100V to 500kV

**Note:** User can select PT primary value as per external PT specifications (Programmable for all values)

**Slave ID****Default Setting :** 1**Range:** 1 to 255

**Note:** Slave Id is for communication purpose. Each meter on same RS485 network should have different address according to Modbus RTU protocol

**Baud Rate****Default Setting:** 9600.**Range:** 300, 600, 1200, 2400, 4800, 9600 & 19200.

**Note:** The baud rate could be on of the six, 300, 600, 1200, 2400, 4800, 9600 & 19200

## Online Page Description

07

X4



- Press VAF (▼) button, the fourth screen shows:
- ✓ Average Voltage (L-N), Current, Power factor of three phase ( $V_{AVG}$ ,  $I_{AVG}$ ,  $PF_{AVG}$ ) & Frequency (Hz)
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

**Note:** In 3  $\emptyset$  3 wire system only L-L / AVG voltage, L-L / AVG current, Average PF & Frequency will be displayed

08

X1



- Press PF (▲) button, the first screen shows:
- ✓ Power factor of each phase (PF1, PF2, PF3) & average power factor ( $PF_{AVG}$ )
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

**Note:** In 3  $\emptyset$  3 wire system only average power factor will be displayed

09

X1



- Press P (←) button, the first screen shows:
- ✓ Active power of each phase (P1, P2, P3) & total power ( $P_{SUM}$ )
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

**Note:** For 3  $\emptyset$  3 wire system, this page will not be available.

## Online Page Description

10

X2



- Press P (←) button, the second screen shows:
- ✓ Reactive power of each phase (Q1, Q2, Q3) & total power ( $Q_{sum}$ )
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

**Note:** For 3 Ø 3 wire system, this page will not be available.

11

X3



- Press P (←) button, the third screen shows:
- ✓ Apparent power of each phase (S1, S2, S3) & total apparent power ( $S_{sum}$ )
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection

**Note:** For 3 Ø 3 wire system, this page will not be available.

12


X4



- Press P (←) button, the fourth screen shows:
- ✓ Active, Reactive, Apparent power of first phase (kW1, kVA1, kVA1) & power factor
  - ✓ Bargraph indicates amount of % current present in the system (Independent of key press)
  - ✓ The lower most display shows total energy (kWh, kVAh, kVAh), based on user selection


**Note:** For 3 Ø 3 wire system, this page will not be available.

## Configuration




**CT Secondary**  
**Default Setting:** 5 A  
**Range:** 1A or 5A

**Note:** User can select from 1A and 5A as per external CT specification



**CT Primary**  
**Default Setting:** 5 A  
**Range:** 1A, 5A to 10,000A (10.0 kA)

**Note:** As per CT secondary selection, CT primary will be 1A to 10000A or 5A to 10000A (Programmable for all values)



**PT Secondary**  
**Default Setting:** 350V  
**Range:** 100V to 500V

**Note:** User can select from 100 to 500V as per external PT specification (Programmable for all values)

 Configuration


**Change Password**  
**Default Setting:** No  
**Range:** No / Yes

**Note:** If user want to change default password, make selection as 'Yes' and proceed. If selection is 'No' then configuration will move on to the network selection page.




**New Password**  
**Default Setting:** 0000  
**Range:** 0000 To 9998

**Note:** After selecting 'Yes' on previous page, user can set new password  
 Use ◀ or ▶ keys to move cursor left or right by one digit each time.  
 Use ▲ or ▼ keys for increasing or decreasing parameters value



**Network Selection**  
**Default Setting:** 3P4W  
**Range:** 3P3W and 3P4W

**Note:** Network selection can be done as per wiring diagram given on Pg. no. 11 and selecting appropriate network selection from configuration eg. for 1 Ø 2 wire / 2 Ø 3 wire connection the network selection should be set to 3P4W and user can make the requisite hardwired connection at the terminals

 Online Page Description

13




X5

Press P (←) button, the fifth screen shows:  
 ✓ Active, Reactive, Apparent power of second phase (kW2, kVAR2, kVA2) & power factor  
 ✓ Bargraph indicates amount of % current present in the system (Independent of key press)  
 ✓ The lower most display shows total energy (kWh, kVARh, kVAh), based on user selection

**Note:** For 3 Ø 3 wire system, this page will not be available.

14




X6

Press P (←) button, the sixth screen shows:  
 ✓ Active, Reactive, Apparent power of third phase (kW3, kVAR3, kVA3) & power factor  
 ✓ Bargraph indicates amount of % current present in the system (Independent of key press)  
 ✓ The lower most display shows total energy (kWh, kVARh, kVAh), based on user selection

**Note:** For 3 Ø 3 wire system, this page will not be available.

15



X7

Press P (←) button, the seventh screen shows:  
 ✓ Total Active, Reactive, Apparent power of all three phase (kW<sub>sum</sub>, kVAR<sub>sum</sub>, kVA<sub>sum</sub>) & power factor  
 ✓ Bargraph indicates amount of % current present in the system (Independent of key press)  
 ✓ The lower most display shows total energy (kWh, kVARh, kVAh), based on user selection

**Note:** In 3 Ø 3 wire system only total L-L power (kW, kVAR, kVA) will be displayed

### Online Page Description

X1



Press E (↔) button, the first screen shows:

- ✓ Total active energy on the bottom most display, Irrespective of page being displayed
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)

**Note:** User can toggle between the 3 types of energy parameters (kWh, kVAh, kVAh) irrespective of page being displayed, by pressing E button

X2



Press E (↔) button, the second screen shows:

- ✓ Total apparent energy on the bottom most display, Irrespective of page being displayed
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)

X3



Press E (↔) button, the third screen shows:

- ✓ Total reactive energy on the bottom most display, Irrespective of page being displayed
- ✓ Bargraph indicates amount of % current present in the system (Independent of key press)

A/M



Press E (↔) button for 3 seconds to toggle between Auto & Manual mode.

**Note:** By default unit operates in auto mode. In auto mode online pages scrolls automatically at the rate of 5 seconds per page. In auto mode when any key is pressed, unit temporarily switches to manual mode and the appropriate page is displayed, also if no key is pressed for 5 sec, unit resumes auto mode

### Configuration

There are 6 dedicated keys labelled as V, I, VAF, PF, P, E. Use these 6 keys to enter into configuration menu / change setting.

**Note:** The settings should be done by a professional, after going through this users manual and understood the application situation.

For the configuration setting mode

- Use ▲ + ▼ keys for 3 sec to enter or exit from the configuration menu.
- Use ◀ or ▶ keys to move cursor left or right by one digit each time.
- Use ▲ or ▼ keys for increasing or decreasing parameters value
- Use ← key to go back to previous page
- Use ↵ key to save the setting and move on to next page



**Password for entering into configuration**

**Default Setting:** 1000

**Range:** 0000 to 9998

**Note:** Access code (Password) needed for getting into configuration menu. Only the person who knows the access code can do the parameter setting